


Caseal Bitumen 102 B

The information in this leaflet is for guidance only. Each manufacturer of manholes offers their own design of manhole and joint profile, therefore if in doubt we recommend seeking advice from your chosen precast manhole ring supplier.

(Fig. 1) Cover Slab to Manhole Ring

DN 900 to DN 1050 use 2 strip of 12 x 60
DN 1200 to DN 1800 use 2 strips of 12 x 80
DN 2100 to DN 3000 use 2 strips of 12 x 120


Fig.1



(Fig. 2) Manhole Ring to Manhole Ring

DN 900 to DN 1050 use 1 strip of 12 x 60
DN 1200 to DN 1800 use 1 strips of 12 x 80
DN 2100 to DN 3000 use 1 strips of 12 x 120


Fig.2



(Fig. 3) Manhole Ring to Reducing or Landing Slab

Remove tongue from manhole ring
DN 900 to DN 1050 use 2 strips of 12 x 60
DN 1200 to DN 1800 use 2 strips of 12 x 80
DN 2100 to DN 3000 use 2 strips of 12 x 120


Fig.3



(Fig. 4) Manhole Ring to Base Slab

Remove tongue from manhole ring
DN 900 to DN 1050 use 2 strips of 12 x 60
DN 1200 to DN 1800 use 2 strips of 12 x 80
DN 2100 to DN 3000 use 2 strips of 12 x 120

Fig.4



(Fig. 5) Box Culvert Joint

Use 1 strip of 25 x 40 inside of socket using primer to prepare surface.
For small units and if the design joint gap is less than 10 mm
22 x 30 can be used.

Fig.5

